



CHECKLIST - WINTERIZATION

Propulsion & Generator:	<u>Engine 1</u>	<u>Engine 2</u>	<u>Generator</u>
o Add fuel stabilizer to fuel tanks	Y / N / NA	Y / N / NA	Y / N / NA
o Change engine oil	Y / N / NA	Y / N / NA	Y / N / NA
o Replace fuel and oil filters	Y / N / NA	Y / N / NA	Y / N / NA
o Check coolant level and freeze point to -20F	Y / N / NA	Y / N / NA	Y / N / NA
o Check transmission fluid level and condition	Y / N / NA	Y / N / NA	Y / N / NA
o Drain water from raw water cooled inboard and I/O engines and risers	Y / N / NA	Y / N / NA	Y / N / NA
o Run antifreeze through raw water intake ensure discharge from exhaust	Y / N / NA	Y / N / NA	Y / N / NA
o Spray fogging oil into intake while running for carbureted gas engines	Y / N / NA	Y / N / NA	Y / N / NA
o Inspect all hoses for signs of softening, cracking or bulges. Replace if practical	Y / N / NA	Y / N / NA	Y / N / NA
o Replace lower unit gear lube	Y / N / NA	Y / N / NA	Y / N / NA
o Spray corrosion inhibitor on engine exterior	Y / N / NA	Y / N / NA	Y / N / NA
Systems:			
o Remove all drain plugs (stern/keel) if applicable	Y / N / NA		
o Drain water heater and bypass it	Y / N / NA		
o Remove fresh water filter and place in galley sink	Y / N / NA		
o Drain freshwater system and tanks, then run antifreeze through system:	Y / N / NA		
o Cabin Showers	Qty:		
o Cockpit Showers	Qty:		
o Sinks	Qty:		
o FW Heads (ensure discharge into holding tank)	Qty:		
o FW Washdowns	Qty:		
o FW City hook up	Qty:		
o Run antifreeze through remaining water systems:	Y / N / NA		
o Refrigeration sumps	Qty:		
o Shower sumps	Qty:		
o RW washdown pump	Qty:		
o Air Con condensation sumps	Qty:		
o Air Con raw water systems and sumps. Ensure discharge from all outlets.	Qty:		
o RW Heads (ensure discharge into holding tank)	Qty:		
o Live wells	Qty:		
o Windshield wipers	Qty:		
o Washer/dryer	Qty:		
	<u>Pump 1</u>	<u>Pump 2</u>	<u>Pump 3</u>
o Verify bilge pumps (elec/manual) operate properly and flush with antifreeze	Y / N / NA	Y / N / NA	Y / N / NA
o Turn battery switch to "OFF" and test bilge pump automatic switch	Y / N / NA		
o Blow out water line with air in ice makers	Y / N / NA		
o Secure all ports and hatches	Y / N / NA		
o Close thru hulls after winterization if boat is in water (except deck drains)	Y / N / NA		
o Open thru hulls after winterization if boat is on land or lift	Y / N / NA		
o Place an appropriate number of dehumidifying devices	Y / N / NA		
o Place thermostatically controlled heater in safe area away from combustibles	Y / N / NA		
o Move any items that can freeze from fridge/icebox to galley sink	Y / N / NA		
o Leave service tag and lock out engine and water heater if possible	Y / N / NA		

***** List all observations, problems or recommendations in timecard notes *****

Technician Signature: _____

Winterization Date: _____